



- NO. 1412 LIPO SAVER 2 CELL Best.-Nr. 230321
- NO. 1413 LIPO SAVER 3 CELL Best.-Nr. 230327
- NO. 1414 LIPO SAVER 4 CELL Best.-Nr. 230328
- NO. 1421 LIPO REGULATOR 4.8V Best.-Nr. 230329
- NO. 1422 LIPO REGULATOR 6V Best.-Nr. 230330

INSTRUCTION

LIPO SAVER

English -

- * **Function** : The power is exhausted completely when the voltage of per cell is at 2.5V, so the warning LED will light to warn "Low Battery" at 3V.
- * **How to use** : Connect Lipo Saver with the Lipo battery pack in parallel. (2, 3, 4-cell use)

LIPO REGULATOR

English -

- * The regulator will change the battery's voltage into the voltage of 4.8V or 6.0V, and then fits the receiver and the servo to use after connecting the Lipo battery pack.
- * The input voltage is between 6V-25V for Lipo regulator 4.8V.
- * The input voltage is between 7V-25V for Lipo regulator 6.0V.